


External Accessories

HGU125 1P

DIN rail adapter (DRA)



477, Bundangsuseo-ro, Bundang-gu, Seongnam-si, Gyeonggi-do, Republic of Korea

A/S Center : Tel) 080-230-7778

Homepage : www.hd-hyundaelectric.com

CAUTION

- Before installation, be sure to read the manual carefully to ensure proper operation
- Installation, maintenance and inspection of the circuit breaker should be performed by persons who are qualified for electric work.

Attention

- Avant l'installation, assurez-vous de lire attentivement le manuel afin de garantir un fonctionnement correct.
- L'installation, la maintenance et l'inspection du disjoncteur doivent être effectuées par des personnes qualifiées pour les travaux électriques.



Precaución

- Antes de la instalación, asegúrese de leer cuidadosamente el manual para garantizar un funcionamiento correcto.
- La instalación, el mantenimiento y la inspección del interruptor automático deben ser realizados por personas calificadas para trabajos eléctricos.

Part list / Liste des pièces / Lista de piezas


Type	DRA12GU
Applied Model (MCCB)	HGU125
	1
	3

Dimension / Dimension / Dimensión



Unit : mm [inch]

Installation / Installation / Instalación



P/H , M3, L7, 3EA

0.91 N·m

Disassembly / Démontage / Desmontaje

