


External Accessories

HGU125/150/250/400/600

Mechanical interlock (MIF)



CAUTION

■ Before installation, be sure to read the manual carefully to ensure proper operation

■ Installation, maintenance and inspection of the circuit breaker should be performed by persons who are qualified for electric work.

Attention

■ Avant l'installation, assurez-vous de lire attentivement le manuel afin de garantir un fonctionnement correct.

■ L'installation, la maintenance et l'inspection du disjoncteur doivent être effectuées par des personnes qualifiées pour les travaux électriques.

Precaución

■ Antes de la instalación, asegúrese de leer cuidadosamente el manual para garantizar un funcionamiento correcto.



■ La instalación, el mantenimiento y la inspección del interruptor automático deben ser realizados por personas calificadas para trabajos eléctricos.

Part list / Liste des pièces / Lista de piezas

Type	MIF12GU	MIF25GU	MIF60GU
Applied Model (MCCB)	HGU125	HGU150 HGU250	HGU400 HGU600
	1	-	-
	-	1	-
	-	-	1
	1	1	1


Installation / Installation / Instalación

HGU125




P/H , #6-32UNC, L85, 4EA
1.5 N·m

HGU150/250




C/H , M3, L8, 4EA
0.91 N·m

HGU400/600




P/H , M4, L14, 4EA
0.6 N·m

Dimensions




Type	"A" mm[inch]
HGU125	25.4[1.0]
HGU150/250	35[1.38]
HGU400/600	46.5[1.83]

Right OFF lock



Left OFF lock



Double OFF lock

